




Front Lance Support Compatibility Guide

Improved Front Lance Support



- 1-Man operation with easy to use and efficient crank handles.
- Stainless Steel Acme thread with brass insert eliminates galling due to corrosion.
- 8 different counter weight combinations make it easier to match lifting power to rattling device weight.
- Roller is easily replaceable & reduces friction on lance during lifting.
- Optional roller materials available.
- Engineered by the OEM putting Safety First.


THE Pipe Yard Equipment Company!



Front Lance Support Compatibility Guide

Due to various design changes throughout the years, compatibility must be verified before installing an Improved Front Lance Support on an existing Pipe Cleaning Machine. Please feel free to contact Hub City Iron Works for any questions regarding compatibility of older machines with Improved Front

1. Identify previously used Front Lance Support brackets.




***THE* Pipe Yard Equipment Company!**



Front Lance Support Compatibility Guide

2. Measure the distance from the top of the Frame Channel to the top of the Front Lance Support Bracket.




THE Pipe Yard Equipment Company!



Front Lance Support Compatibility Guide

3. Measure the center distance between the holes on the brackets.




***THE* Pipe Yard Equipment Company!**



Front Lance Support Compatibility Guide

4. Measure the center distance between the holes between brackets.



***THE* Pipe Yard Equipment Company!**